

RPS and Video Controller RS232



Copyright © 2021 by Planar Systems, Inc.

Contents of this publication may not be reproduced in any form without permission of Planar Systems, Inc.

Trademark Credits

Windows™ is a trademark of Microsoft Corp.

All other names are trademarks or registered trademarks of their respective companies.

Disclaimer

The information contained in this document is subject to change without notice. Planar Systems, Inc. makes no warranty of any kind with regard to this material. While every precaution has been taken in the preparation of this manual, the Company shall not be liable for errors or omissions contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this material.

Warranty and Service Plans

Planar warranty and service plans will help you maximize your investment by providing great support, display uptime, and performance optimization. From post-sale technical support to a full suite of depot services, our services are performed by trained Planar employees. When you purchase a Planar product, you get more than a display, you get the service and support you need to maximize your investment. To find the latest warranty and service information regarding your Planar product, please visit <http://www.planar.com/support/>

Manual Part Number: 020-1332-001

Contents

| | |
|--|----|
| RS232 Communication | 4 |
| Applicable Models | 4 |
| RS232 Setup | 4 |
| Connecting the RS232 Cable..... | 5 |
| RJ45 and DB9 Standard RS232 Pinout | 6 |
| RS232 Protocol..... | 7 |
| Command Structure | 7 |
| Protocol Encoding | 8 |
| Examples..... | 9 |
| RS232 Codes | 10 |
| Advanced | 11 |
| Basic Control | 14 |
| Color Balance..... | 15 |
| Configuration | 16 |
| Time Zone Setting–Operands | 26 |
| Monitoring Setup..... | 27 |
| Presets | 28 |
| Security | 29 |
| Status | 30 |
| Zone Setup and Control | 34 |
| Sending Serial Commands via USB..... | 37 |
| Installing the USB drivers | 37 |
| Using the RPS USB Connection..... | 44 |
| Sending Serial Commands Via TCP or UDP | 46 |

RS232 Communication

RS232 control is not necessary for operation, but is a convenient way to control the Planar Remote Power Supply and Planar Video Controller from a control system at a distance. Plus, you can send inquiries to the system and find out the current settings and values. RS232 connections are made with standard straight-through cables.

Note: Serial communication can occur over RS232, USB-B or LAN. See the sections "Sending Serial Commands via USB" on page 37 and "Sending Serial Commands Via TCP or UDP" on page 46 for details on those physical connections.

Applicable Models

This RS-232 user manual applies to all Planar RPS and Video Controller models. RS232 user manuals for other products can be found at www.planar.com/support/.


RS232 Setup

The RS232 connection must use the following settings:

- 19200 baud rate
- 8 data bits
- 1 stop bit
- No parity bit
- No HW (RTS/CTS) or SW (XON/XOFF) flow control

Connecting the RS232 Cable

The RS232 cable will connect to a PC or control system, depending on your setup.




Remote Power Supply Models



Video Controller Models


RJ45 and DB9 Standard RS232 Pinout



Rj-45 Jack
(Female)

| Pin RJ45 Jack | Signal | Description |
|---------------|--------|-------------|
| 6 | Rx | Receive |
| 3 | Tx | Transmit |
| 4, 5 | GND | Ground |
| 1, 2, 7, 8 | | No Connect |

| Pin DB9 | Signal | Description |
|------------------|--------|-------------|
| 2 | Rx | Receive |
| 3 | Tx | Transmit |
| 5 | GND | Ground |
| 1, 4, 6, 7, 8, 9 | | No Connect |



RS232 Protocol

Command Structure

[OPCODE] (MODIFIERS) [OPERATOR] [OPERANDS] [TERM]

- OPCODE is the command code (e.g. "IR.CODE"). This can be written either using the named command code (see the "Command Code" column in the table) or the numeric command code (see the "Numeric Command Code" column in the table).
- MODIFIERS are modifier values [e.g. "(STATIC)"]. There are zero or more modifiers for each command. The modifiers can be written either with their named value or their numeric value (see "Examples" on page 9). See the "Modifiers" column in the table.
- OPERATOR is the action to be performed. See the "Operators" column in the table.
 - '=' writes the setting value.
 - '?' reads the setting value in name form (see "Examples" on page 9).
 - '#' reads the setting value in numeric form (see "Examples" on page 9).
 - '+' increments the setting value.
 - '-' decrements the setting value.
 - ':' indicates that the message is a response to one of the following operators: =?#+-
 - '!ERR' indicates that the message is a failure response. An error code will be listed after the "ERR", with a space before it. Error codes are as follows:
 - ERR 1: Invalid syntax
 - ERR 2: [Reserved for future use]
 - ERR 3: Command not recognized
 - ERR 4: Invalid modifier
 - ERR 5: Invalid operands
 - ERR 6: Invalid operator
 - '@ACK' indicates that the message is an acknowledgment (ACK) to a command that has no operator.
 - '^NAK' indicates that the message is a negative acknowledgment (NAK) to a command. This indicates that the command was received but cannot be processed at this time.
 - TIMEOUT indicates that a command was not received by a host piece of equipment. This may be due to disconnected equipment or a poor communication path.
 - [No operator] denotes an action. In this case, there's no operator and no operand.

- OPERAND indicates the data to be sent or the return message. In some cases, there can be multiple operands. See the "Operands" column in the table.
 - Enumerated operands can be written either with their named value or their numeric value (see "Examples" on page 9).
 - String operands are written with quotation marks at the beginning and end. Example: "this is a string operand". Special characters, [CR], [LF], " and \ can be included in a string by escaping them with the \ character (see "Examples" on page 9).
 - Integer (or signed integer / unsigned integer) are always numeric values.
 - Fixed point operands are numeric values with fractional parts. They use decimal point notation.
 - Note that enumerated and integer values can be written either in decimal or hexadecimal. For example, a decimal value of '50' can be written in hexadecimal as '0x32'.
- TERM is the termination character for the command. This can either be the ASCII carriage return character (0x0D), the ASCII line feed character (0x0A) or a semicolon. The response will use the same termination character.

Protocol Encoding

- All parts of the command structure are case insensitive (e.g. "SYSTEM.STATE", "system.state" and "System.StaTe" are all the same). Responses will always be in capital letters.
- Excessive white space is allowed (e.g. "AUTO.ON=0", "AUTO.ON = 0" and "AUTO.ON = 0" are all the same).
- Modifiers and operands can be separated by commas, spaces or both (e.g. "PANEL.ACTIVE=0 0 1280 720", "PANEL.ACTIVE=0,0,1280,720" and "PANEL.ACTIVE=0, 0, 1280, 720" are all the same). Responses will always separate with one space between modifiers and operands).

Examples

Note: [CR] is the ASCII carriage return character (0x0D). Not all commands shown are available.

| Command | Response | Notes |
|---|---|--|
| ipv4.address(static)="10.15.0.220" [CR] | IPV4.ADDRESS(STATIC):"10.15.0.220" [CR] | Example command with a string operator |
| reset[CR] | RESET@ACK [CR] | Example action command (no operator or operand) |
| reset[CR] | RESET^NAK [CR] | Example action command that cannot be processed at this time |
| brightness @@ [CR] | BRIGHTNESS!ERR 1 [CR] | Example of an invalid syntax ("@" isn't a valid operator) |
| fake.command = 1 [CR] | FAKE.COMMAND!ERR 3 [CR] | Example of an invalid opcode ("FAKE.COMMAND" doesn't exist) |
| brightness(zone.999) = 100 [CR] | BRIGHTNESS(ZONE.999)!ERR 4 [CR] | Example of an invalid modifier ("ZONE.999" isn't a valid modifier for "BRIGHTNESS") |
| brightness="new value" [CR] | BRIGHTNESS!ERR 5 [CR] | Example of an invalid operand (the Brightness command doesn't accept a string operand) |
| model.id = 1 [CR] | MODEL.ID!ERR 6 [CR] | Example of an invalid operator (cannot write to this command) |

RS232 Codes

Notes:

- The examples are written with the command first and the *response in italics*.
Example:
 - Command: IPV4.ADDRESS(STATIC)=192.168.0.12
 - Response: *IPV4.ADDRESS(STATIC):192.168.0.12*
- In many instances, a modifier may be omitted and the display will replace it with a default value. For example, the default modifier for the IPV4.ADDRESS command is STATIC, so the following two commands are identical:
 - IPV4.ADDRESS(STATIC)=192.168.0.12
 - IPV4.ADDRESS=192.168.0.12
- '!' in the Operators column indicates that the command accepts the execute operator, which uses no operator symbol. The '!' symbol is not included in the command.

Advanced

| Command | Description | Numeric Command Code | Operators | Modifiers | Operands | Example | Notes | Standalone Component Command | Firmware Version Active | Functional in Fast Start Standby | Functional in Low Power Standby |
|---------------|-----------------------|----------------------|-----------|-------------------------------------|----------|---|---|------------------------------|--------------------------|----------------------------------|---------------------------------|
| ALERT.CHECK | Check Alert Status | 2326 | ! | | | ALERT.CHECK ALERT.CHECK@ACK | Clears existing alerts and evaluates the system for alerts that are may be active. Resends alerts based on the alert settings report via check boxes. | No | 6.0 | Yes | No |
| ALERT.CLEAR | Clear Alerts | 2323 | ! | 0=ALL 1=WEB 2=EMAIL 3=SNMP | | ALERT.CLEAR(WEB) ALERT.CLEAR(WEB):@ACK ALERT.CLEAR ALERT.CLEAR:@ACK | Clears alerts for the specified UI. If no modifier is provided, all alerts are cleared. | Yes | 5.1 | Yes | Yes |
| DEVICE.REBOOT | Unit Connected Reboot | 2405 | ! | Blank VC# PS# PSW# | | DEVICE.REBOOT(PS2) DEVICE.REBOOT(PS2)@ACK | Reboots the specified device. No modifier reboots all LAN connected components. For all device reboot, see SYSTEM.REBOOT. | Yes | 2.1 10.0 ¹ | Yes | No |
| HELP | Help | 2300 | =? | 0 = FIRST 2147483647 = NEXT | String | HELP=OSD.STATUS HELP:"OSD.STATUS\ Numeric Value: 1308\ Operators: ?\ No Modifiers\ 1 Operand(s)\ Operand #1: Unsigned Integer\ DISABLE 0\ ENABLE 1\ OFF 0\ ON 1\ NO 0\ YES 1\ FALSE 0\ TRUE 1 | Displays information for each command. To get a list of all commands, first enter the following command: HELP(FIRST)? Then enter the following command continuously until it returns NAK: HELP(NEXT)? | Yes | 1.x | Yes | Yes |

| Command | Description | Numeric Command Code | Operators | Modifiers | Operands | Example | Notes | Standalone Component Command | Firmware Version Active | Functional in Fast Start Standby | Functional in Low Power Standby |
|---------------|----------------------|----------------------|-----------|-----------|--|--|---|------------------------------|-------------------------|----------------------------------|---------------------------------|
| KEY | Remote Key Codes | 1200 | =? | | 0=UP 1=DOWN 2=MENU 9=EXIT 12=LEFT 13=ENTER 14=PREV 15=RIGHT 17=KEY.1 18=KEY.2 19=KEY.3 20=KEY.4 21=KEY.5 22=KEY.6 23=KEY.7 24=KEY.8 25=KEY.9 32=KEY.0 257=STDBY.ENTER 258=STDBY.EXIT 260=TOP 261=PRESETS 262=PRESET1 263=PRESET2 264=PRESET3 265=PRESET4 280=WALL 281=COLOR 282=MISC 283=ARROW.LEFT 284=ARROW.RIGHT 285=STAR.STAR | KEY=262 KEY:262 KEY=STAR.STAR KEY:STAR.STAR | Refer to OSM section for key definitions: UP=ARROW UP DOWN=ARROW DOWN MENU=MENU TOGGLE EXIT=EXIT MENU LEVEL LEFT=ARROW LEFT ENTER=SELECT PREV=PREVIOUS MENU RIGHT=ARROW RIGHT KEY.1=NUMBER 1 KEY.2=NUMBER 2 KEY.3=NUMBER 3 KEY.4=NUMBER 4 KEY.5=NUMBER 5 KEY.6=NUMBER 6 KEY.7=NUMBER 7 KEY.8=NUMBER 8 KEY.9=NUMBER 9 KEY.0=NUMBER 0 STDBY.ENTER=SYSTEM OFF STDBY.EXIT=SYSTEM ON TOP=TOP MENU HIGHLIGHT PRESETS=OPEN PRESET MENU PRESET1=SWITCH TO PRESET 1 PRESET2=SWITCH TO PRESET 2 PRESET3=SWITCH TO PRESET 3 PRESET4=SWITCH TO PRESET 4 WALL=OPEN BIG PICTURE MENU COLOR=OPEN COLOR BALANCE MENU MISC=OPEN BRIGHTNESS MENU ARROW.LEFT=CYCLE PANEL # LEFT IN COLOR BALANCE ARROW.RIGHT=CYCLE PANEL # RIGHT IN COLOR BALANCE STAR.STAR=SELECT ALL PANELS IN COLOR BALANCE | No | 2.0 | Yes | Yes |
| LOCAL.DIMMING | Enable Local Dimming | 1415 | =?+- | | 0=OFF 1=ON | LOCAL.DIMMING? LOCAL.DIMMING:OFF | Toggles between local dimming on or off. Only effective on LCD panels which support capability. | No | 2.0 6.0 ¹ | Yes | Yes |
| LOOPROUTE | Loop Signal Output | 112 | =? | VC# | 1=IN1 2=IN2 3=IN3 4=IN4 5=DP | LOOPROUTE(VC2)=IN3 LOOPROUTE(VC2):IN3 | Gets / sets the input that will be routed to the loop out on the specified video controller. | No | 4.0 | Yes | No |

| Command | Description | Numeric Command Code | Operators | Modifiers | Operands | Example | Notes | Standalone Component Command | Firmware Version Active | Functional in Fast Start Standby | Functional in Low Power Standby |
|----------------------------|-----------------------------|----------------------|-----------|----------------|--|--|---|------------------------------|-------------------------|----------------------------------|---------------------------------|
| LOOP.ROUTE. AUTO | Auto Loop Routing | 113 | =? | VC# | 0=DISABLE=OFF=NO=FALSE 1=ENABLE=ON=YES=TRUE | LOOP.ROUTE.AUTO(VC2)? LOOP.ROUTE.AUTO(VC2):TRUE | Gets / sets the loop out on the specified video controller will be overridden by zone setup signal requests. | No | 4.0 | No | No |
| MASTER.SWITCH | Master Component Activation | 1913 | =?+- | VC# PS# | 0=DISABLE=OFF=NO=FALSE 1=ENABLE=ON=YES=TRUE | MASTER.SWITCH(VC1)=1 MASTER.SWITCH:TRUE | Gets / sets the specified equipment to be the master component. Only one component in an interconnected system must be set to master or conflicts will occur. This overrides the physical switch on the RPS | Yes | 2.0 5.1 ¹ | Yes | Yes |
| MESSAGE.CLEAR | System Messages | 2325 | ! | | | MESSAGE.CLEAR MESSAGE.CLEAR:@ACK | Clears any system messages from the log | Yes | 5.1 | Yes | Yes |
| PANEL.ACTIVE. AUTO | Automatic Panel Active Area | 1521 | =? | | 0=DISABLE=OFF=NO=FALSE 1=ENABLE=ON=YES=TRUE | PANEL.ACTIVE.AUTO? PANEL.ACTIVE.AUTO:YES | When enabled panel active rects are computed automatically. Disable to use PANEL.ACTIVE to override automatic active area. | No | 3.0 | No | No |
| PANEL.POWER | Panel On/Off | 1538 | =? | PN# ALL | 0=DISABLE=OFF=NO=FALSE 1=ENABLE=ON=YES=TRUE | PANEL.POWER(PN2)? PANEL.POWER(PN2):0 | Gets / sets the specified luminating devices to on or off | No | 7.0 9.0 ¹ | Yes | No |
| PANEL.SYNC. ENABLE | Panel Sync Enabled | 1520 | =? | | 0=DISABLE=OFF=NO=FALSE 1=ENABLE=ON=YES=TRUE | PANEL.SYNC.ENABLE? PANEL.SYNC.ENABLE:YES | Gets / sets the scan line inversion for even row displays (LCD only). | No | 2.1 | No | No |
| RESET.PANEL | Panel Reset | 1523 | ! | 0=ALL 1-999 | | RESET.PANEL(3) RESET.PANEL(3):@ACK | Resets connected display equipment to factory state. | No | 3.0 | Yes | No |
| VC.AUTO.ENABLE. ADDRESS | Auto Enable VC | | =? | | 0=DISABLE=OFF=NO=FALSE 1=ENABLE=ON=YES=TRUE | VC.AUTO.ENABLE.ADDRESS=0 VC.AUTO.ENABLE.ADDRESS:OFF | Gets / sets the auto enabling of VC addressing to on or off. | No | 8.0 | Yes | Yes |

¹ Updated

Basic Control

| Command | Description | Numeric Command Code | Operators | Modifiers | Operands | Example | Notes | Standalone Component Command | Firmware Version Active | Functional in Fast Start Standby | Functional in Low Power Standby |
|---------------------|-----------------------|----------------------|-----------|--|---|---|---|------------------------------|--------------------------|----------------------------------|---------------------------------|
| BACKLIGHT.INTENSITY | Brightness Intensity | 1400 | =?+- | | 0-100 | BACKLIGHT.INTENSITY? BACKLIGHT.INTENSITY:80 | Gets / sets the intensity of the display. | No | 2.0 | No | No |
| POWER.COMMAND | External Device Power | 2702 | = | PSW# or PSW,ALL PSW,GROUP PSW,NAME PSW,NAME PSW,NAME PS# | 0=DISABLE=OFF=NO=FALSE 1=ENABLE=ON=YES=TRUE 2=CYCLE | POWER.COMMAND(PSW3)=OFF POWER.COMMAND(PSW3):"OFF" POWER.COMMAND(PSW,NAME)=CYCLE "LEFT COLUMN" 5 POWER.COMMAND(PSW,NAME): "CYCLE" "LEFT COLUMN" "5" | Sets the main power output of the specified device. Second modifier may be used to change bulk states of devices by predefined tags. Operand CYCLE may be followed by an integer that denotes a delay time in seconds for the specified device to change from the opposite power state back to its current power state. If no number is entered, 10 seconds is used. CYCLE does not apply to modifier PS#. Power supplies set to off toggle the AC input to the RPSM. | Yes | 8.0 10.0 ¹ | Yes | No |
| QCONFIG | Big Picture Configure | 505 | =? | | VC#.IN# | QCONFIG=VC2.IN3 QCONFIG:VC2.IN3 | Gets / sets Big Picture of wall to specified sources. | No | 2.0 | No | No |
| SYSTEM.POWER | System Power | 1408 | =?+- | | 0=DISABLE=OFF=NO=FALSE 1=ENABLE=ON=YES=TRUE | SYSTEM.POWER=ON SYSTEM.POWER:ON | Toggles system power between on and off. | No | 1.x | Yes | Yes |
| SYSTEM.REBOOT | System Reboot | 2402 | ! | | | SYSTEM.REBOOT SYSTEM.REBOOT:@ACK | Reboots the system and all system powered connected components. | No | 2.0 | Yes | Yes |

¹ Updated

Color Balance

| Command | Description | Numeric Command Code | Operators | Modifiers | Operands | Example | Notes | Standalone Component Command | Firmware Version Active | Functional in Fast Start Standby | Functional in Low Power Standby |
|--------------------|-----------------------|----------------------|-----------|--|---|--|---|------------------------------|-------------------------|----------------------------------|---------------------------------|
| BACKLIGHT.OFFSET | LCD Backlight Offset | 1424 | =?+- | PN# 0=ALL | -100..100 | BACKLIGHT.OFFSET(3)=10 BACKLIGHT.OFFSET(3):10 | Gets / sets panel backlight offset values for brightness matching of LCDs. | No | 4.0 | Yes | No |
| COLOR.TEMP | Color Temperature | 1510 | =? | PN# or integer NONE is all | 0=3200K 1=5500K 2=6500K 3=8500K 4=9300K 5=NATIVE 6=CUSTOM | COLOR.TEMP? COLOR.TEMP=8500K | Gets / sets wall color temperature. Note: 5500K and NATIVE is for LCD product only and 9300K is for LED product only. To set a custom color temperature for LED, it must be set through the Planar Control Software interface. A @NAK return indicates all panels are not set the same. | No | 4.0 | Yes | No |
| GRAY.BALANCE.GAMMA | Color Balance - Gray | 1504 | =? | Panel IDand.... 0=RED 1=GREEN 2=BLUE 255=ALL | 1.8 .. 2.6 | GRAY.BALANCE.GAMMA(1 red)? GRAY.BALANCE.GAMMA(1 RED):2.200000 | Gets / sets the gray balance value (gamma) for the given LCD and color channel. | No | 4.0 | No | No |
| RESET.BALANCE | Color Balance Reset | 1506 | ! | | | RESET.BALANCE RESET.BALANCE:@ACK | Resets the color balance of all LCDs back to the last saved state | No | 4.0 | No | No |
| WALL.RGB.GAIN | LED RGB Gain Values | 611 | =? | 0=RED 1=GREEN 2=BLUE 255=ALL | 0.000 THRU 100.000 | WALL.RGB.GAIN(RED)? WALL.RGB.GAIN(RED):100 | Gets / sets the red, green and blue gain settings for the wall. This command applies to LED open pixel architectures only. | No | 8.0 | No | No |
| WHITE.BALANCE | White Balance Setting | 1525 | =? | Panel IDand.... 0=RED 1=GREEN 2=BLUE 255=ALL | 0.0 - 100.0 | WHITE.BALANCE(1 RED)? WHITE.BALANCE(1 RED):100.000000 | Gets / sets the white balance value for the given LCD and color channel | No | 4.0 | No | No |

Configuration

| Command | Description | Numeric Command Code | Operators | Modifiers | Operands | Example | Notes | Standalone Component Command | Firmware Version Active | Functional in Fast Start Standby | Functional in Low Power Standby |
|-------------------|----------------------------|----------------------|-----------|------------------------|--|--|--|------------------------------|-------------------------|----------------------------------|---------------------------------|
| AUTO.LAYOUT | Auto Wall Layout | 608 | ! | PN# | | AUTO.LAYOUT AUTO.LAYOUT@ACK AUTO.LAYOUT(PN2) AUTO.LAYOUT(PN2)@ACK | For LCD products, the command uses the position sensors to auto layout the panels within a system. No modifier used for LCD products. When a modifier is used, the effect will be on LED cabinets within the range of the panel indicated by the modifier. | No | 7.0 | Yes | No |
| AUTO.ON | Auto Power On | 1407 | =? | | 0=DISABLED 1=POWER_ON 2=PREVIOUS_STATE | AUTO.ON=POWER_ON AUTO.ON:POWER_ON | Gets / sets if the system will turn on if the AC power is applied. | No | 1.x 2.0 ¹ | Yes | Yes |
| BACKLIGHT.MAXIMUM | Maximum Brightness Setting | 1417 | =?+- | | 40-100 | BACKLIGHT.MAXIMUM=50 BACKLIGHT.MAXIMUM:50 | Gets / sets maximum wall brightness. | No | 4.0 | Yes | No |
| BACKLIGHT.MODE | Auto Brightness | 1402 | =? | | 0=AUTO 1=MANUAL (default) | BACKLIGHT.MODE=MANUAL BACKLIGHT.MODE:MANUAL | Gets / sets wall brightness adjustment mode, where AUTO enables the system to automatically change brightness based on ambient sensor value. | No | 4.0 | Yes | No |
| CABINET.INPUT | Active Cabinet Input | 1534 | =? | PN# | 0=AUTO 1=HDMI1 2=HDMI2 | CABINET.INPUT(PN2)=AUTO CABINET.INPUT(PN2):AUTO | Gets / sets the active input setting on the first cabinet of the specified panel. | Yes | 5.1 | Yes | No |
| CUSTOM.COLOR | Custom Color Display | 1314 | =? | PN# 0=ALL (default) | 0-1023 | CUSTOM.COLOR(PN4)=100 255 10 CUSTOM.COLOR(PN4):100 255 10 | Gets / sets in order: Red, Green, Blue color value. When set for a panel, also enables PATTERN(panel)=CUSTOM. When set for ALL, this command ONLY sets the custom color value and does not activate any PATTERN. PATTERN command equal to NONE required to remove. | No | 4.0 | No | No |
| DEVICE.DELETE | Delete External Device | 2700 | ! | PSW# | | DEVICE.DELETE(PSW1) DEVICE.DELETE(PSW1)@ACK | Deletes the specified device from system. | No | 8.0 | Yes | Yes |
| DEVICE.GROUP | External Device Group | 2704 | =? | PSW# | String | DEVICE.GROUP(PSW2)="LEFT WALL" DEVICE.GROUP(PSW2):"LEFT WALL" | Gets / sets for specified device the group affiliation associated. Quotes must be used to set any group names that have spaces. | No | 8.0 | Yes | Yes |
| DEVICE.NAME | External Device Name | 2703 | =? | PSW# | String | DEVICE.NAME(PSW4)="LEFT COLUMN" DEVICE.NAME(PSW4):"LEFT COLUMN" | Gets / sets for specified device the unique name associated. Quotes must be used to set any names that have spaces. | No | 8.0 | Yes | Yes |

| Command | Description | Numeric Command Code | Operators | Modifiers | Operands | Example | Notes | Standalone Component Command | Firmware Version Active | Functional in Fast Start Standby | Functional in Low Power Standby |
|-------------------|--------------------------|----------------------|-----------|---------------------------|---|--|--|------------------------------|--|----------------------------------|---------------------------------|
| FIRMWARE.UPDATE | Update Firmware | 2200 | =?! | | String | FIRMWARE.UPDATE="usb:firmware.pkg" FIRMWARE.UPDATE:"acknowledged" FIRMWARE.UPDATE? FIRMWARE.UPDATE:"USB.FIRMWARE.PKG" 0 1 "success" 1 | No operator checks the attached USB drive for latest default filename structure firmware .pkg file in numeric order and updates to latest. = operator is used to assign specific file name for update ? Operator will return status of update. Data only valid before device reboot. Only applies to the attached equipment. | Yes | 1.x 2.1 ¹ 7.0 ¹ | Yes | No |
| FIRMWARE.VERSION | Get unit FW version | 2320 | ? | PS# VC# PN# PSW# | String | FIRMWARE.VERSION? FIRMWARE.VERSION:4.0.569 | Gets current firmware version of the specified device. No modifier returns system master firmware version. | Yes | 4.0 10.0 ¹ | Yes | No |
| GENLOCK.AUTO | Auto Genlock | 1518 | =? | | 0=DISABLE=OFF=NO=FALSE 1=ENABLE=ON=YES=TRUE | GENLOCK.AUTO? GENLOCK.AUTO:ON | Gets / sets whether the equipment is set up to automatically genlock to a source. | No | 2.1 | Yes | No |
| GENLOCK.DISABLE | Disable Genlock | 1519 | =? | | 0=DISABLE=OFF=NO=FALSE 1=ENABLE=ON=YES=TRUE | GENLOCK.DISABLE=0 GENLOCK.DISABLE:FALSE | Gets / sets whether the genlock feature is disabled. | No | 2.1 | Yes | No |
| GENLOCK.REFERENCE | Genlock Reference Source | 1516 | =? | VC# | 0=SYNC_IN 1=IN1 2=IN2 3=IN3 4=IN4 5=DP 6=INTERNAL | GENLOCK.REFERENCE=0 GENLOCK.REFERENCE:SYNC_IN | Gets / sets the sync reference source to be used with the connected equipment. Note: DP not an option for High Speed Link VCs.. | No | 2.1 10.0 ¹ | Yes | No |
| HDR.ENABLE | Enable HDR | 610 | =?+- | | 0=DISABLE=OFF=FALSE =AUTO 1=ENABLE=YES=TRUE=HDR10 | HDR.ENABLE? HDR.ENABLE:ENABLE | Gets / sets the system capability to process HDR source signals to the display. | No | 8.0 9.0 ¹ | Yes | Yes |
| ID | Component ID | 1911 | =? | VC# PS# PN# PSW# | String | ID(VC3)=4 ID(VC3):4 | Gets / sets the ID of the component specified. | No | 1.x 2.0 ¹ 6.0 ¹ 10.0 ¹ | Yes | No |
| IDENTIFY | Identify Power Supply ID | 1910 | ! | String | String | IDENTIFY(P2) IDENTIFY(P2):@ACK | Sends command to system for the system master control LED on the specified remote power supply to blink 3 times rapidly and cycle this behavior several times. | No | 2.0 | Yes | No |
| INPUT.BRIGHTNESS | Input Brightness | 200 | =? | VC#.IN# | 0-100 | INPUT.BRIGHTNESS(VC1.IN4)=56 INPUT.BRIGHTNESS(VC1.IN4):56 | Gets / sets the input brightness value for the specified input. | No | 6.0 | Yes | No |

| Command | Description | Numeric Command Code | Operators | Modifiers | Operands | Example | Notes | Standalone Component Command | Firmware Version Active | Functional in Fast Start Standby | Functional in Low Power Standby |
|------------------|--------------------|----------------------|-----------|--|---|---|--|------------------------------|--|----------------------------------|---------------------------------|
| INPUT.COLORSPACE | Input Colorspace | 207 | =? | VC#.IN# | 0=REC601 1=REC709 2=RGB 3=RGB VIDEO 4=AUTO 5=UNKNOWN | INPUT.COLORSPACE(VC1.IN1)? INPUT.COLORSPACE(VC1.IN1):REC709 | Gets / sets the input colorspace for the specified input. | No | 6.0 7.0 ¹ | Yes | No |
| INPUT.CONTRAST | Input Contrast | 201 | =? | VC#.IN# | 0-100 | INPUT.CONTRAST(VC5.IN3)? INPUT.CONTRAST(VC5.IN3):22 | Gets / sets the input contrast value for the specified input. | No | 6.0 | Yes | No |
| INPUT.GAIN | Input RGB Gain | 209 | =? | VC#.IN#and.... 0=RED 1=GREEN 2=BLUE 255=ALL | 0-200 | INPUT.GAIN(VC2.IN3 0)? INPUT.GAIN(VC2.IN3 RED):85 INPUT.GAIN(VC3.IN1 ALL)=128 INPUT.GAIN(VC3.IN1 ALL)=128 128 128 | Gets / sets the input gains for red, green and/or blue. Multiple data returned is red, green, blue. | No | 6.0 7.0 ¹ | Yes | No |
| INPUT.OFFSET | Input RGB Offset | 210 | =? | VC#.IN#and.... 0=RED 1=GREEN 2=BLUE 255=ALL | 0-100 | INPUT.OFFSET(VC2.IN3 0)? INPUT.OFFSET(VC2.IN3 RED):85 INPUT.OFFSET(VC3.IN1 ALL)=128 INPUT.OFFSET(VC3.IN1 ALL)=128 128 128 | Gets / sets the input offsets for red, green and/or blue. Multiple data returned is red, green, blue. | No | 6.0 | Yes | No |
| INPUT.RESET | Reset Input Values | 217 | ! | VC#.IN# | | INPUT.RESET=VC2.IN2 INPUT.RESET:VC2.IN2 | Sets all input parameter values back to factory default for specified input. | No | 6.0 | Yes | No |
| IPV4.ADDRESS | IP Address | 1204 | =? | ACTIVE STATIC MASTER DHCP VC# PSW# [None = ACTIVE (for reads only)] [None = STATIC (for writes only)] | String | IPV4.ADDRESS(DHCP)? IPV4.ADDRESS:"10.15.0.60" IPV4.ADDRESS(MASTER)=192.168.0.15 IPV4.ADDRESS(MASTER)="192.168.0.15" IPV4.ADDRESS(VC2, STATIC)? IPV4.ADDRESS(VC2, STATIC):192.168.0.113 IPV4.ADDRESS(PSW3)=192.168.0.223 IPV4.ADDRESS(PSW3):192.168.0.223 | Gets the master equipment specified IP Address. Sets the master static IP Address. Modifiers MASTER and STATIC are equivalent. Use of modifier PSW# only changes the system master expected equipment IP address, not IP address of equipment. | No | 2.0 8.0 ¹ 10.0 ¹ | Yes | Yes |
| IPV4.ENABLE | Configuration | 1230 | =? | MASTER STATIC | 0=DISABLE=OFF=NO=FALSE 1=ENABLE=ON=YES=TRUE | IPV4.ENABLE=1 IPV4.ENABLE:1 | Toggles the equipment to use dynamic host configuration protocol. Modifier MASTER and STATIC are equivalent. For DHCP, see NETWORK.DHCP. | No | 8.0 | Yes | Yes |

| Command | Description | Numeric Command Code | Operators | Modifiers | Operands | Example | Notes | Standalone Component Command | Firmware Version Active | Functional in Fast Start Standby | Functional in Low Power Standby |
|-----------------------|----------------------|----------------------|-----------|---|--|---|---|------------------------------|--|----------------------------------|---------------------------------|
| IPV4.GATEWAY | Default Gateway | 1206 | =? | ACTIVE STATIC MASTER DHCP [None = ACTIVE (for reads only)] [None = STATIC (for writes only)] | String | IPV4.GATEWAY(DHCP)? IPV4.GATEWAY(DHCP):"10.15.0.1" IPV4.GATEWAY(1)=192.168.0.1 IPV4.GATEWAY(1):"192.168.0.1" | Gets the master equipment specified network gateway. Sets the master static network gateway. Modifiers MASTER and STATIC are equivalent. | No | 2.0 8.0 ¹ | Yes | Yes |
| IPV4.NETMASK | Subnet Mask | 1205 | =? | ACTIVE STATIC MASTER DHCP [None = ACTIVE (for reads only)] [None = STATIC (for writes only)] | String | IPV4.NETMASK(2)? IPV4.NETMASK(0):"255.255.254.0" IPV4.NETMASK(STATIC)=255.255.255.254 IPV4.NETMASK(STATIC):"255.255.255.254" | Gets the master equipment specified subnet. Sets the master static subnet. Modifiers MASTER and STATIC are equivalent. | No | 2.0 8.0 ¹ | Yes | Yes |
| IR.CODE | Remote Code | 1210 | =?+- | | 0-65535 | IR.CODE=12345 IR.CODE:12345 | Gets / sets remote code to work with different remotes. | No | 1.x | Yes | Yes |
| IR.LOCK | Remote Lock | 1202 | =?+- | | 0=DISABLE=OFF=NO=FALSE 1=ENABLE=ON=YES=TRUE | IR.LOCK=ENABLE IR.LOCK:ENABLE | Toggles the equipment from responding to commands sent by a remote. | No | 1.x | Yes | Yes |
| KEY.LOCK | Front Keypad Lock | 1201 | =?+- | | 0=DISABLE=OFF=NO=FALSE 1=ENABLE=ON=YES=TRUE | KEY.LOCK=DISABLE KEY.LOCK:DISABLE | Toggles the equipment from responding to commands from the keypad. | No | 2.0 | Yes | No |
| MATRIX.LAYOUT.COLUMNS | Matrix Array Columns | 600 | ? | | Integer | MATRIX.LAYOUT.COLUMNS? MATRIX.LAYOUT.COLUMNS:6 | Returns the number of columns in the configured wall. | No | 4.0 | Yes | Yes |
| MATRIX.LAYOUT.PANEL | Array Panel ID | 602 | ? | Column# and Row# | Integer | MATRIX.LAYOUT.PANEL(1 3)? MATRIX.LAYOUT.PANEL(1 3):7 | Returns the panel ID number for the specified column/row coordinate in a configured wall. | No | 4.0 | Yes | Yes |
| MATRIX.LAYOUT.ROWS | Matrix Array Rows | 601 | ? | | Integer | MATRIX.LAYOUT.ROWS? MATRIX.LAYOUT.ROWS:4 | Returns the number of rows in the configured wall. | No | 4.0 | Yes | Yes |
| MENU.PANEL | OSD Panel Display | 1311 | =? | | Integer | MENU.PANEL? MENU.PANEL:4 | Gets / sets the panel ID on which the main OSD is displayed. | No | 2.0 | No | No |
| MODEL.NAME | Component Model | 2306 | ? | PS# VC# PN# PSW# | String | MODEL.NAME? MODEL.NAME:"RPS220-3" MODEL.NAME(PN3)? MODEL.NAME(PN3):"MX55U" | Returns the directly connected equipment model name without modifier. Returns the specified equipment's model name with modifier. | Yes | 1.x 4.0 ¹ 10.0 ¹ | Yes | No |

| Command | Description | Numeric Command Code | Operators | Modifiers | Operands | Example | Notes | Standalone Component Command | Firmware Version Active | Functional in Fast Start Standby | Functional in Low Power Standby |
|-------------------------|------------------------------|----------------------|-----------|---|--|--|---|------------------------------|--------------------------|----------------------------------|---------------------------------|
| NETWORK.CONFIG.MODIFIED | Network Change | 1216 | ? | | 0=DISABLE=OFF=NO=FALSE 1=ENABLE=ON=YES=TRUE | NETWORK.CONFIG.MODIFIED? NETWORK.CONFIG.MODIFIED:TRUE | Returns whether the system network configuration has changed. If yes, a reboot is required. | No | 2.0 | Yes | Yes |
| NETWORK.DHCP | DHCP | 1207 | =?+- | | 0=DISABLE=OFF=NO=FALSE 1=ENABLE=ON=YES=TRUE | NETWORK.DHCP? NETWORK.DHCP:ON | Toggles the equipment to use dynamic host configuration protocol. For static IP enabling, see IPV4.ENABLE. | No | 1.x | Yes | Yes |
| NETWORK.DNS1 | DNS Server 1 | 1212 | =? | 0=ACTIVE 1=STATIC [None = ACTIVE (for reads only)] [None = STATIC (for writes only)] | String | NETWORK.DNS1(0)? NETWORK.DNS1(0):"192.168.1.10" | Gets / sets the domain name server of the equipment. | No | 1.x | Yes | Yes |
| NETWORK.DNS2 | DNS Server 2 | 1213 | =? | 0=ACTIVE 1=STATIC [None = ACTIVE (for reads only)] [None = STATIC (for writes only)] | String | NETWORK.DNS2(0)? NETWORK.DNS2(0):"192.168.1.20" | Gets / sets the backup domain name server of the equipment. | No | 1.x | Yes | Yes |
| NETWORK.MAC | Component MAC Address | 1203 | ? | PS# VC# PSW# | String | NETWORK.MAC? NETWORK.MAC:"12:34:56:AB:CD:EF" NETWORK.MAC(VC2)? NETWORK.MAC(VC2):C4:F3:12:73:77:04 | Returns the master component MAC address. No modifier returns the master component MAC address. | No | 1.x 10.0 ¹ | Yes | Yes |
| NETWORK.PING | Network Ping | 1211 | = | | String | NETWORK.PING=10.15.0.60 NETWORK.PING:"0" | Pings other network IP addresses. "0" = Time out (10 seconds) "1" = Success | No | 1.x | Yes | Yes |
| NTP.ENABLE | Network Time Protocol Enable | 1209 | =? | | 0=OFF 1=ON | NTP.ENABLE=ON NTP.ENABLE:ON | Enables or disables NTP. | Yes | 5.1 | Yes | Yes |
| NTP.SERVER | Network Time Protocol Server | 1214 | =? | | See Table: Time Zone Setting-Operands | NTP.SERVER="0.pool.us.ntp.org" NTP.SERVER:"0.pool.us.ntp.org" | Gets / sets the NTP server used by the NTP client. | Yes | 5.1 | Yes | Yes |
| OSD.ALLOW.POPUP | OSD Popup | 1300 | =?+- | | 0=DISABLE=OFF=NO=FALSE 1=ENABLE=ON=YES=TRUE | OSD.ALLOW.POPUP? OSD.ALLOW.POPUP:ON | Gets / sets the whether popup messages will be displayed on the panels. | No | 3.0 | No | No |
| OSD.MARGIN | OSD Offset | 1313 | =?+- | | 0-400 | OSD.MARGIN=10 OSD.MARGIN:10 | Gets / sets the OSD position in pixels away from edges set by OSD.POSITION. No effect on OSD.POSITION=CENTER. | No | 3.0 | No | No |

| Command | Description | Numeric Command Code | Operators | Modifiers | Operands | Example | Notes | Standalone Component Command | Firmware Version Active | Functional in Fast Start Standby | Functional in Low Power Standby |
|-------------------------|-------------------------|----------------------|-----------|-----------|---|---|---|------------------------------|--------------------------|----------------------------------|---------------------------------|
| OSD.POSITION | OSD Position | 1301 | =?+- | | 0=CENTER 1=UPPER.LEFT 2=UPPER.RIGHT 3=BOTTOM.LEFT 4=BOTTOM.RIGHT | OSD.POSITION=2 OSD.POSITION:UPPER.RIGHT | Positions the OSD on each panel to the indicated position on the panel. | No | 3.0 | No | No |
| OSD.TIMEOUT | OSD Timeout | 1304 | =?+- | | 0=OFF 30=30.SECONDS 60=60.SECONDS 120=120.SECONDS 240=240.SECONDS | OSD.TIMEOUT? OSD.TIMEOUT:60 | Gets/ sets the output resolution to automatically (default) detect the connected panel resolution or provide a method to manually set the mode to be 1920x1080 or 3840x2160 resolution. Modifier is only used to query an individual VC's mode. | No | 3.0 | No | No |
| OUTPUT.COLOR.DEPH | Bit Depth | 603 | =? | | 8, 10, 12 | OUTPUT.COLOR.DEPH? OUTPUT.COLOR.DEPH:10 | Gets / sets the color bit depth processed by the system. | No | 9.0 | Yes | No |
| OUTPUT.MODE | VC Output Resolution | 604 | =? | VC# | 0=AUTO 1=1080p 2=4K | OUTPUT.MODE=4k OUTPUT.MODE:4K OUTPUT.MODE(VC)? OUTPUT.MODE(VC2):4K | Gets / sets the output resolution to automatically (default) detect the connected panel resolution or provide a method to manually set the mode to be 1920x1080 or 3840x2160 resolution. | Yes | 7.0 | Yes | No |
| OUTPUT.VREFRESH | Panel Refresh Rate | 605 | =? | | 50 60 | OUTPUT.VREFRESH=50 OUTPUT.VREFRESH:50 | Gets / sets the system panel refresh rate. Reboot required after setting. | No | 7.0 | Yes | No |
| PANEL.ACTIVE | Panel Active Area | 1522 | =? | Integer | 0-65535 | PANEL.ACTIVE(1)? PANEL.ACTIVE(1):0 0 1280 720 | Gets / sets the active area x, y, width, and height in panel pixel coordinates | No | 3.0 | No | No |
| PANEL.BRIGHTNESS.OFFSET | Panel Brightness Offset | 1437 | =?+- | PN# | -100 to 100 | PANEL.BRIGHTNESS.OFFSET(PN1)=5 PANEL.BRIGHTNESS.OFFSET(PN1):5.000 000 | Gets / sets the panel's offset brightness for use with color balancing | No | 7.0 | Yes | No |
| PANEL.COUNT | Number of Panels | 1527 | ? | | Integer | PANEL.COUNT? PANEL.COUNT:12 | Returns the number of panels configured in the system. | No | 4.0 | Yes | No |
| PANEL.HEIGHT | Panel Height in Pixels | 1544 | ? | PN# | Integer | PANEL.HEIGHT(10)? PANEL.HEIGHT(10):720 | Gets the pixel height of the specified panel. | No | 8.0 10.0 ¹ | Yes | Yes |
| PANEL.ID | Set Panel ID | 1524 | = | 1-65535 | 1-65535 | PANEL.ID(5)=3 PANEL.ID(5):3 | Sets an existing panel ID to a new panel ID. If there are duplicate IDs, the first found will be changed. | No | 3.0 | No | No |

| Command | Description | Numeric Command Code | Operators | Modifiers | Operands | Example | Notes | Standalone Component Command | Firmware Version Active | Functional in Fast Start Standby | Functional in Low Power Standby |
|----------------|-----------------------|----------------------|-----------|--|--|--|--|------------------------------|--------------------------|----------------------------------|---------------------------------|
| PANEL.LIST | Panel ID List | 1526 | ? | Integer 1-PANEL.COUNTand/or..... Integer 1-PANEL.COUNT | String | PANEL.LIST? PANEL.LIST:1 2 3 5 6 7 8 9 10 PANEL.LIST(3)? PANEL.LIST:3 PANEL.LIST(4 8)? PANEL.LIST:4 5 6 7 8 | Returns a list of up to 64 panel IDs that are currently recognized by the system. The optional modifiers enable listing when there are more than 64 panels. The first modifier gives the 1-based index into the list for the first returned value. If the second modifier is omitted, only one value is returned. When given, the second value specifies the end index of the returned values. | No | 4.0 | Yes | No |
| PANEL.POSITION | Panel Array Position | 1528 | ? | PN# | String | PANEL.POSITION(PN2)? PANEL.POSITION(PN2):3 2 | Returns the column/row position in an array of the specified panel. | No | 4.0 | Yes | No |
| PANEL.RECT | Panel Display Area | 1529 | ? | Integer | Integer | PANEL.RECT(5)? PANEL.RECT(5):1920 1080 1920 1080 | For specified panel in configured wall, returns in order: x offset dimension from zero x position in wall, y offset dimension from zero y position in wall, x display pixels, y display pixels. | No | 4.0 | Yes | No |
| PANEL.WIDTH | Panel Width in Pixels | 1543 | ? | PN# | Integer | PANEL.WIDTH(10)? PANEL.WIDTH(10):1080 | Gets the pixel width of the specified panel. | No | 8.0 10.0 ¹ | Yes | Yes |
| PANEL.XY | Cabinet Origin | 1537 | ? | Integer | | PANEL.XY(3)? PANEL.XY(3):0 2160 | Returns the pixel position of the 0,0 coordinate of the specified panel in X and Y dimensions. | No | 6.0 | Yes | No |
| PATTERN | Test Pattern | 1307 | =? | | 0=NONE 1=BLACK 2=WHITE 3=RED 4=GREEN 5=BLUE 6=CYAN 7=MAGENTA 8=YELLOW 9=GRAY 10=CUSTOM_COLOR 11=RED_SCALE 12=GREEN_SCALE 13=BLUE_SCALE 14=GRAY_SCALE 15=LOGO 16=GRID 18=CONTRAST 20=COLOR_BARS | PATTERN? PATTERN:GREEN | Gets / sets the test pattern displayed for all displays connected to the system. | No | 2.0 | No | No |

| Command | Description | Numeric Command Code | Operators | Modifiers | Operands | Example | Notes | Standalone Component Command | Firmware Version Active | Functional in Fast Start Standby | Functional in Low Power Standby |
|----------------------------|--------------------------------------|----------------------|-----------|--|--|--|---|------------------------------|-------------------------|----------------------------------|---------------------------------|
| POWER.SAVING.DELAY | No Source Power Mode Time | 1439 | =? | | 0=CUSTOM 60=1.MINUTE 300=5.MINUTES 900=15.MINUTES 1800=30.MINUTES 3600=60.MINUTES | POWER.SAVING.DELAY=900 POWER.SAVING.DELAY:900 POWER.SAVING.DELAY? POWER.SAVING.DELAY:15.MINUTES | Gets / sets the time the system will wait before activating the POWER.SAVE.MODE. See POWER.SAVING.DELAY.MINUTES for custom times. | No | 8.0 | Yes | Yes |
| POWER.SAVING.DELAY.MINUTES | No Source Power Mode Custom Time | 1440 | =? | | 1.000000 thru 120.000000 | POWER.SAVING.DELAY.MINUTES=100 POWER.SAVING.DELAY.MINUTES:100.00 0000 | Gets / sets the custom time for POWER.SAVING.DELAY. | No | 8.0 | Yes | Yes |
| POWER.SAVING.MODE | No Source Power Mode | 1440 | =? | | 0=DISABLED 1=FAST.START 2=LOW.POWER | POWER.SAVING.MODE? POWER.SAVING.MODE:DISABLED | Gets / sets the system power mode for when a source displayed on the video wall is absent. | No | 8.0 | Yes | Yes |
| PS.COUNT | Number of Power Supplies | 1428 | ? | | Integer | PS.COUNT? PS.COUNT:4 | Returns the number of power supplies configured in the system. | No | 4.0 | Yes | No |
| PS.LIST | Power Supply ID List | 1427 | ? | Integer 1-PS.COUNTand/or..... Integer 1-PS.COUNT | String | PS.LIST? PS.LIST:1 2 3 4 PS.LIST(3)? PS.LIST:3 PS.LIST(1 3)? PS.LIST:1 2 3 | Returns a list of up to 64 power supply IDs that are currently recognized by the system. The optional modifiers enable listing when there are more than 64 power supplies. The first modifier gives the 1-based index into the list for the first returned value. If the second modifier is omitted, only one value is returned. When given, the second value specifies the end index of the returned values. | No | 4.0 | Yes | No |
| PS.VERSION | Power supply module software version | 2318 | ? | 1-4 | String | PS.VERSION(2)? PS.VERSION(2):"1.0.600" | Returns the firmware version of the indicated power supply module within the directly connected power supply. | Yes | 1.x | Yes | No |
| RESET | Factory Reset | 2400 | ! | | | RESET RESET:@ACK | Resets the system to factory defaults. Full AC power cycle may be required or system reboot. | No | 1.x | Yes | No |
| RESET.CANCEL | Cancel Factory Reset | 2406 | ! | | | RESET.CANCEL RESET.CANCEL:@ACK | Cancels pending factory reset prior to reboot or AC cycle. | No | 2.0 | Yes | Yes |
| RESET.LAYOUT | Reset Wall Layout | 609 | ! | | | RESET.LAYOUT RESET.LAYOUT@ACK | Resets wall layout back to default. | No | 7.0 | Yes | No |
| SERIAL.DEVICE | Serial Baud Rate | 1220 | =? | | 9600 19200 38400 57600 115200 | SERIAL.DEVICE? SERIAL.DEVICE:19200 | Gets / sets the baud rate for the connected component. Default is 19200. Note: Data bits, parity and stop bits are always 8, N, 1. | Yes | 2.0 | Yes | Yes |

| Command | Description | Numeric Command Code | Operators | Modifiers | Operands | Example | Notes | Standalone Component Command | Firmware Version Active | Functional in Fast Start Standby | Functional in Low Power Standby |
|------------------------|--------------------------------|----------------------|-----------|-------------------|--|--|---|------------------------------|-------------------------|----------------------------------|---------------------------------|
| SERIAL.NUMBER | Component Serial number | 2303 | ? | PS# VC# PN# | String | SERIAL.NUMBER(PN1)? SERIAL.NUMBER(PN1):"ABCD1234" | No modifier returns the directly attached component serial number. Using a modifier returns the serial number of the specified equipment. | Yes | 1.x 4.0 ¹ | Yes | No |
| SOURCE.ABSENT.COLOR | No Source Display Color | 606 | =? | | 0=BLACK 1=GRAY 2=RED 3=GREEN 4=BLUE 5=CYAN 6=YELLOW 7=MAGENTA 8=CUSTOM | SOURCE.ABSENT.COLOR=2 SOURCE.ABSENT.COLOR:2 | Gets / sets the configured color for a zone when an expected source is absent. | No | 7.0 | Yes | No |
| SOURCE.ABSENT.RGB | Custom No Source Display Color | 607 | =? | | 0 to 1023 | SOURCE.ABSENT.RGB=1000 1000 1000 SOURCE.ABSENT.RGB:1000 1000 1000 | Gets / sets the custom color option in SOURCE.ABSENT.COLOR. Three values entered in order are Red, Green, Blue. Setting automatically sets SOURCE.ABSENT.COLOR to CUSTOM. | No | 7.0 | Yes | No |
| STANDBY.MODE | Power Standby Mode | 1425 | =? | | 0=FAST.START 1=LOW.POWER | STANDBY.MODE? STANDBY.MODE:FAST.START | Gets / sets the power standby mode of the system. | No | 4.0 | Yes | Yes |
| SYSTEM.PANEL.VERSION | Panel Firmware Version | 2322 | ? | | String | SYSTEM.PANEL.VERSION? SYSTEM.PANEL.VERSION:"1.5.267" | Returns the panel firmware version. | No | 5.1 | Yes | No |
| SYSTEM.POWER.TIE | External Device Power Behavior | 2705 | =? | PSW# ALL | 0=NO 1=FAST.START 2=LOW.POWER 3=CUSTOM | SYSTEM.POWER.TIE(PSW5)? SYSTEM.POWER.TIE(PSW5):FAST.START SYSTEM.POWER.TIE(ALL)=2 SYSTEM.POWER.TIE(ALL):2 | Gets / sets the specified external power device behavior based on the system power mode. | No | 8.0 | Yes | Yes |
| TIMEZONE | Time Zone Setting | 1208 | =?+- | | See "Time Zone Setting-Operands" on page 26. | TIMEZONE=5 TIMEZONE:5 TIMEZONE=UTCM0800.PACIFIC.TIME.US. CANADA TIMEZONE:UTCM0800.PACIFIC.TIME.US. CANADA | Gets / sets the timezone for the system. | Yes | 5.1 | Yes | Yes |
| TIMEZONE.STRING | Time Zone Status | 1221 | ? | | String | TIMEZONE.STRING? TIMEZONE.STRING:"(UTC-08:00) Pacific Time (US & Canada)" | Returns the timezone string for the system. | Yes | 5.1 | Yes | Yes |
| VC.AUTO.ADDRESS.ENABLE | Automatic VC IP Address | 2328 | =? | | 0=DISABLE=OFF=NO=FALSE 1=ENABLE=ON=YES=TRUE | VC.AUTO.ADDRESS.ENABLE? VC.AUTO.ADDRESS.ENABLE:TRUE | Gets / sets the system auto setting of individual IP addresses on the static network. | No | 8.0 | Yes | Yes |
| VC.COUNT | Number of Video Controllers | 1604 | ? | | Integer | VC.COUNT? VC.COUNT:4 | Returns the number of video controllers configured in the system. | No | 4.0 | Yes | No |

| Command | Description | Numeric Command Code | Operators | Modifiers | Operands | Example | Notes | Standalone Component Command | Firmware Version Active | Functional in Fast Start Standby | Functional in Low Power Standby |
|------------------|--------------------------|----------------------|-----------|--|--------------------|--|--|------------------------------|-------------------------|----------------------------------|---------------------------------|
| VC.LIST | Video Controller ID List | 1603 | ? | Integer 1-VC.COUNTand/or..... Integer 1-VC.COUNT | String | VC.LIST? VC.LIST:1 2 3 4 VC.LIST(3)? VC.LIST:3 VC.LIST(2 4) VC.LIST:2 3 4 | Returns a list of up to 64 video controller IDs that are currently recognized by the system. The optional modifiers enable listing when there are more than 64 video controllers. The first modifier gives the 1-based index into the list for the first returned value. If the second modifier is omitted, only one value is returned. When given, the second value specifies the end index of the returned values. | No | 4.0 | Yes | No |
| VC.START.ADDRESS | VC Starting IP Address | 2327 | =? | | XXX.XXX.XXX.XXX/XX | VC.START.ADDRESS=192.168.0.120/24 VC.START.ADDRESS:"192.168.0.120/24" | Gets / sets the first VC's xxxx IP address and subnet. All additional VCs will be assigned an IP address in numeric order from this assigned address. | No | 8.0 | Yes | Yes |
| WALL.BRIGHTNESS | Wall Brightness Setting | 1436 | =?+ | | 0-100 | WALL.BRIGHTNESS? WALL.BRIGHTNESS:80.000000 | Gets / sets the global wall brightness. | No | 7.0 | Yes | No |
| WALL.HEIGHT | Wall Pixel Height | 613 | =? | | Integer | WALL.HEIGHT=3840 WALL.HEIGHT:3840 | Gets / sets the wall height pixels. | No | 8.0 | Yes | Yes |
| WALL.WIDTH | Wall Pixel Width | 612 | =? | | Integer | WALL.WIDTH=2160 WALL.WIDTH:2160 | Gets / sets the wall width pixels. | No | 8.0 | Yes | Yes |

¹ Updated

Time Zone Setting—Operands

| | |
|---|--|
| 0=UTCM1200.INTERNATIONAL.DATE.LINE.WEST | 53=UTCP0200.TRIPOLI |
| 1=UTCM1100.COORDINATED.UNIVERSAL.TIMEM11 | 54=UTCP0300.BAGHDAD |
| 2=UTCM1000.HAWAII | 55=UTCP0300.KUWAIT.RIYADH |
| 3=UTCM0900.ALASKA | 56=UTCP0300.MINSK |
| 4=UTCM0800.BAJA.CALIFORNIA | 57=UTCP0300.MOSCOW.ST.PETERSBURG.VOLGOGRAD.RTZ.2 |
| 5=UTCM0800.PACIFIC.TIME.US.CANADA | 58=UTCP0300.NAIROBI |
| 6=UTCM0700.ARIZONA | 59=UTCP0330.TEHRAN |
| 7=UTCM0700.CHIHUAHUA.LA.PAZ.MAZATLAN | 60=UTCP0400.ABU.DHABI.MUSCAT |
| 8=UTCM0700.MOUNTAIN.TIME.US.CANADA | 61=UTCP0400.BAKU |
| 9=UTCM0600.CENTRAL.AMERICA | 62=UTCP0400.IZHEVSK.SAMARA.RTZ.3 |
| 10=UTCM0600.CENTRAL.TIME.US.CANADA | 63=UTCP0400.PORT.LOUIS |
| 11=UTCM0600.GUADALAJARA.MEXICO.CITY.MONTERREY | 64=UTCP0400.TBILISI |
| 12=UTCM0600.SASKATCHEWAN | 65=UTCP0400.YEREVAN |
| 13=UTCM0500.BOGOTA.LIMA.QUITO.RIO.BRANCO | 66=UTCP0430.KABUL |
| 14=UTCM0500.CHETUMAL | 67=UTCP0500.ASHGABAT.TASHKENT |
| 15=UTCM0500.EASTERN.TIME.US.CANADA | 68=UTCP0500.EKATERINBURG.RTZ.4 |
| 16=UTCM0500.INDIANA.EAST | 69=UTCP0500.ISLAMABAD.KARACHI |
| 17=UTCM0430.CARACAS | 70=UTCP0530.CHENNAI.KOLKATA.MUMBAI.NEW.DELHI |
| 18=UTCM0400.ASUNCION | 71=UTCP0530.SRI.JAYAWARDENEPURA |
| 19=UTCM0400.ATLANTIC.TIME.CANADA | 72=UTCP0545.KATHMANDU |
| 20=UTCM0400.CUIABA | 73=UTCP0600.ASTANA |
| 21=UTCM0400.GEORGETOWN.LA.PAZ.MANAUS.SAN.JUAN | 74=UTCP0600.DHAKA |
| 22=UTCM0330.NEWFOUNDLAND | 75=UTCP0600.NOVOSIBIRSK.RTZ.5 |
| 23=UTCM0300.BRASILIA | 76=UTCP0630.YANGON.RANGOON |
| 24=UTCM0300.CAYENNE.FORTALEZA | 77=UTCP0700.BANGKOK.HANOI.JAKARTA |
| 25=UTCM0300.CITY.OF.BUENOS.AIRES | 78=UTCP0700.KRASNOYARSK.RTZ.6 |
| 26=UTCM0300.GREENLAND | 79=UTCP0800.BEIJING.CHONGQING.HONG.KONG.URUMQI |
| 27=UTCM0300.MONTEVIDEO | 80=UTCP0800.IRKUTSK.RTZ.7 |
| 28=UTCM0300.SALVADOR | 81=UTCP0800.KUALA.LUMPUR.SINGAPORE |
| 29=UTCM0300.SANTIAGO | 82=UTCP0800.PERTH |
| 30=UTCM0200.COORDINATED.UNIVERSAL.TIMEM02 | 83=UTCP0800.TAIPEI |
| 31=UTCM0100.AZORES | 84=UTCP0800.ULAANBAATAR |
| 32=UTCM0100.CABO.VERDE.IS | 85=UTCP0900.OSAKA.SAPPORO.TOKYO |
| 33=UTC.CASABLANCA | 86=UTCP0900.SEOUL |
| 34=UTC.COORDINATED.UNIVERSAL.TIME | 87=UTCP0900.YAKUTSK.RTZ.8 |
| 35=UTC.DUBLIN.EDINBURGH.LISBON.LONDON | 88=UTCP0930.ADELAIDE |
| 36=UTC.MONROVIA.REYKJAVIK | 89=UTCP0930.DARWIN |
| 37=UTCP0100.AMSTERDAM.BERLIN.BERN.ROME.STOCKHOLM.VIENNA | 90=UTCP1000.BRISBANE |
| 38=UTCP0100.BELGRADE.BRATISLAVA.BUDAPEST.LJUBLJANA.PRAGUE | 91=UTCP1000.CANBERRA.MELBOURNE.SYDNEY |
| 39=UTCP0100.BRUSSELS.COPENHAGEN.MADRID.PARIS | 92=UTCP1000.GUAM.PORT.MORESBY |
| 40=UTCP0100.SARAJEVO.SKOPJE.WARSAW.ZAGREB | 93=UTCP1000.HOBART |
| 41=UTCP0100.WEST.CENTRAL.AFRICA | 94=UTCP1000.MAGADAN |
| 42=UTCP0100.WINDHOEK | 95=UTCP1000.VLADIVOSTOK.MAGADAN.RTZ.9 |
| 43=UTCP0200.AMMAN | 96=UTCP1100.CHOKURDAKH.RTZ.10 |
| 44=UTCP0200.ATHENS.BUCHAREST | 97=UTCP1100.SOLOMON.IS.NEW.CALEDONIA |
| 45=UTCP0200.BEIRUT | 98=UTCP1200.ANADYR.PETROPAVLOVSK.KAMCHATSKY.RTZ.11 |
| 46=UTCP0200.CAIRO | 99=UTCP1200.AUCKLAND.WELLINGTON |
| 47=UTCP0200.DAMASCUS | 100=UTCP1200.COORDINATED.UNIVERSAL.TIMEP12 |
| 48=UTCP0200.HARARE.PRETORIA | 101=UTCP1200.FIJI |
| 49=UTCP0200.HELSINKI.KYIV.RIGA.SOFIA.TALLINN.VILNIUS | 102=UTCP1300.NUKU.ALOFA |
| 50=UTCP0200.ISTANBUL | 103=UTCP1300.SAMOA |
| 51=UTCP0200.JERUSALEM | 104=UTCP1400.KIRITIMATI.ISLAND |
| 52=UTCP0200.KALININGRAD.RTZ.1 | |

Monitoring Setup

| Command | Description | Numeric Command Code | Operators | Modifiers | Operands | Example | Notes | Standalone Component Command | Firmware Version Active | Functional in Fast Start Standby | Functional in Low Power Standby |
|--------------------------|-------------------------------|----------------------|-----------|-------------------------------------|--|--|--|------------------------------|-------------------------|----------------------------------|---------------------------------|
| CABINET.POLLING.ENABLE | LED Cabinet Monitoring Enable | 1532 | =? | | 0=DISABLE=OFF=NO=FALSE 1=ENABLE=ON=YES=TRUE | CABINET.POLLING.ENABLE=YES CABINET.POLLING.ENABLE:@ACK | Gets / sets LED cabinet monitoring enabling. | Yes | 5.1 7.0 ¹ | Yes | Yes |
| CABINET.POLLING.INTERVAL | LED Cabinet Polling Interval | 1533 | =? | | 1000 .. 10000 | CABINET.POLLING.INTERVAL=2000 CABINET.POLLING.INTERVAL:2000 | Gets / sets the cabinet polling interval. Valid values are between 1000 and 10000. Longer time intervals reduce chance of false error reporting. | Yes | 5.1 | Yes | Yes |
| RESET.ALERTS | Alert Reset | 2409 | ! | 0=ALL 1=WEB 2=EMAIL 3=SNMP | | RESET.ALERTS(WEB) RESET.ALERTS(WEB):@ACK | Resets alert settings to the factory default for the specified UI. If no modifier is provided, it is treated as all. | No | 5.1 | Yes | Yes |

Presets

| Command | Description | Numeric Command Code | Operators | Modifiers | Operands | Example | Notes | Standalone Component Command | Firmware Version Active | Functional in Fast Start Standby | Functional in Low Power Standby |
|---------------|--------------------|----------------------|-----------|---|-------------------|--|--|------------------------------|-------------------------|----------------------------------|---------------------------------|
| PRESET.ACTIVE | Active Preset | 2010 | ? | | Integer | PRESET.ACTIVE? PRESET.ACTIVE:2 | Returns the active displayed preset slot number. 0 (zero) indicates the current zone layout has been modified since the last preset was recalled, or that no preset has ever been recalled. | No | 4.0 | Yes | No |
| PRESET.COUNT | Saved Presets | 2006 | ? | | Integer | PRESET.COUNT? PRESET.COUNT:8 | Returns the number of configured presets in the system. | No | 2.0 | Yes | Yes |
| PRESET.DELETE | Delete Preset | 2000 | ! | Integer 1-999 | | PRESET.DELETE(3) PRESET.DELETE(3):@ACK | Deletes specified preset from the specified preset slot. | No | 2.0 | Yes | Yes |
| PRESET.LIST | Preset List | 2008 | ? | Integer 1-PRESET.COUNTand/or.... Integer 1-PRESET.COUNT | String | PRESET.LIST? PRESET.LIST:1 2 3 4 PRESET.LIST(3)? PRESET.LIST:3 PRESET.LIST(2 3)? PRESET.LIST:2 3 | Returns a list of up to 64 preset slot numbers that are currently utilized (has a preset saved with that slot number). The optional modifiers enable listing when there are more than 64 saved presets. The first modifier gives the 1-based index into the list for the first returned value. If the second modifier is omitted, only one value is returned. When given, the second value specifies the end index of the returned values. | No | 4.0 | Yes | No |
| PRESET.NAME | Name Preset | 2003 | =? | Integer 1-999 | String | PRESET.NAME(2)? PRESET.NAME(2):"4K Video" PRESET.NAME(2)=All 4K Sources PRESET.NAME(2):"All 4K Sources" | Gets / sets the user assigned name of the specified preset slot number. | No | 2.0 | Yes | Yes |
| PRESET.RECALL | Load Preset | 2001 | ! | Integer 1-999 | | PRESET.RECALL(4) PRESET.RECALL(4):@ACK | Assigns the specified preset slot as the active zone layout for the system. | No | 2.0 | No | No |
| PRESET.SAVE | Save Preset | 2002 | ! | Integer 1-999 | | PRESET.SAVE(8) PRESET.SAVE(8):@ACK | Saves the specified preset slot number with the active zone layout. Overwrites any existing saved preset with specified slot number, or makes a new preset with specified slot number if needed. | No | 2.0 | No | No |
| PRESET.SLOT | Preset Memory Slot | 2011 | =? | Integer 1-999 | Integer 1-999 | PRESET.SLOT(2)=1 PRESET.SLOT(2):1 | Sets the memory slot location of a specified valid preset. Returns if a preset slot value is in use. See PRESET.STATUS AND PRESET.LIST. | No | 4.0 | Yes | No |
| PRESET.STATUS | Preset Status | 2009 | ? | Integer 1-999 | 0=EMPTY 1=FULL | PRESET.STATUS(1)? PRESET.STATUS(1):FULL | Returns whether a specified preset slot currently has information stored. | No | 2.0 4.0 ¹ | Yes | Yes |

¹ Updated

Security

| Command | Description | Numeric Command Code | Operators | Modifiers | Operands | Example | Notes | Standalone Component Command | Firmware Version Active | Functional in Fast Start Standby | Functional in Low Power Standby |
|----------------|-------------------|----------------------|-----------|-----------|--|--|---|------------------------------|-------------------------|----------------------------------|---------------------------------|
| COMMAND.ENABLE | Enable TCP/UDP | 2411 | =? | 0=NETWORK | 0=DISABLE=OFF=NO=FALSE 1=ENABLE=ON=YES=TRUE | COMMAND.ENABLE(NETWORK)? COMMAND.ENABLE(NETWORK):TRUE | Gets / sets port 57 on the TCP/UDP port to enabled or disabled. | No | 7.0 | Yes | Yes |
| PASSWORD.SET | Set User Password | 2410 | = | String | String | PASSWORD.SET=123 PASSWORD.SET="123" | Sets the password for the 'admin' account in the WallDirector software. Command may not be set via port 57 service. | Yes | 7.0 | Yes | Yes |

Status

| Command | Description | Numeric Command Code | Operators | Modifiers | Operands | Example | Notes | Standalone Component Command | Firmware Version Active | Functional in Fast Start Standby | Functional in Low Power Standby |
|----------------------|---------------------------|----------------------|-----------|--|---|---|--|------------------------------|--|----------------------------------|---------------------------------|
| ALERT.COUNT | System Alert Count | 2319 | ? | | Integer | ALERT.COUNT? ALERT.COUNT:21 | Returns the number of configurable system alerts. | No | 2.0 5.1 ¹ | Yes | Yes |
| BREAKER.OPEN | Tripped Breaker Monitor | 1435 | ? | PS# | | BREAKER.OPEN(PS1)? BREAKER.OPEN:NO NO | Returns if the breaker position is ON(NO) or OFF(YES) in sequence from 1 to number of outputs on the model RPS. | No | 5.1 | Yes | No |
| CABINET.INPUT.STATUS | Cabinet Input Status | 1535 | ? | Panel ID ...and.... Cabinet X position ...and.... Cabinet Y position | 0=DISABLE=OFF=NO=FALSE 1=ENABLE=ON=YES=TRUE ...and... 0=NONE 1=HDMI1 2=HDMI2 ...and... 0=DISABLE=OFF=NO=FALSE 1=ENABLE=ON=YES=TRUE ...and... 0=DISABLE=OFF=NO=FALSE 1=ENABLE=ON=YES=TRUE | CABINET.INPUT.STATUS(pn2 1 2)? CABINET.INPUT.STATUS(PN2 1 2): YES HDMI1 YES NO | Returns the following about a cabinet: Connected (YES/NO), Active Input (HDMI1, HDMI2), HDMI1 present (YES/NO), HDMI2 present (YES/NO). | No | 5.1 7.0 ¹ | Yes | No |
| CONNECTION | Panel Connection | 1542 | ? | PN# ...or... VC#.OUT# | VC#.OUT# ...or... PN#.IN# | CONNECTION(PN2)? CONNECTION(PN2):VC3.OUT6 CONNECTION(PN3)? CONNECTION(PN3):VC2.OUT1 VC2.OUT2 CONNECTION(VC2.OUT1)? CONNECTION(VC2.OUT1):PN3.IN1 | Gets the output(s) of the VC that a panel is connected to or the input of a panel that a VC output is connected to. For 4k panels, the first value returned is the primary (IN1) and the second value is the secondary (IN2) connection. | No | 6.0 7.0 ¹ | Yes | No |
| CONNECTED | Device Connected | 1426 | ? | PS# VC# PN# PSW# | 0=DISABLE=OFF=NO=FALSE 1=ENABLE=ON=YES=TRUE | CONNECTED(VC3)? CONNECTED(VC3):NO | Gets connected status of the indicated device. With no modifier, gets connected status of the directly connected device. | Yes | 4.0 7.0 ¹ 10.0 ¹ | Yes | No |
| FAN.STATUS | VC Fan Status | 1433 | ? | VC# | 0=OK 1=FAULT | FAN.STATUS(VC1)? FAN.STATUS:OK | Returns the specified VC fan status. | Yes | 5.1 | Yes | No |
| FUSE.OPEN | Auxiliary RPS Fuse Status | 1434 | ? | PS# | 0=NO 1=YES | FUSE.OPEN(PS1)? FUSE.OPEN:YES YES | Returns the fuse status for each fuse on the specified device. | Yes | 5.1 | Yes | No |

| Command | Description | Numeric Command Code | Operators | Modifiers | Operands | Example | Notes | Standalone Component Command | Firmware Version Active | Functional in Fast Start Standby | Functional in Low Power Standby |
|----------------------|-----------------------------|----------------------|-----------|---|--|--|--|------------------------------|-------------------------|----------------------------------|---------------------------------|
| GENLOCK.LOCKED | Genlock Status | 1517 | ? | VC# or ALL | 0=DISABLE=OFF=NO=FALSE 1=ENABLE=ON=YES=TRUE | GENLOCK.LOCKED(VC1)? GENLOCK.LOCKED(VC1):YES | Returns whether the equipment is locked to a sync source. | No | 2.1 | Yes | No |
| INFOFRAME | HDR Data Header | 305 | ? | VC#.IN# VC#.OUT# | Hex String | INFOFRAME(VC1.IN2)? INFOFRAME(VC1.IN2):"87011A0D0200488A08393421AA9B9619FC08133D4240E8033200000000000" | Gets the HDR meta data for the specified input or output of systems with HDR enabled. | No | 8.0 | Yes | No |
| INPUT.INFO | Get Input Information | 300 | ? | VC#.IN#and optional.... 0=BRIEF (DEFAULT) 1=ALL | String | INPUT.INFO(VC1.IN4)? INPUT.INFO(VC1.IN4):TRUE 1440 900 P 59.89 INPUT.INFO(VC1.IN4 BRIEF)? INPUT.INFO(VC1.IN4 BRIEF):TRUE 1440 900 P 59.89 INPUT.INFO(VC1.IN4 ALL)? INPUT.INFO(VC1.IN4 ALL):TRUE 1440 900 P 59.89 RGB 444 24 1904 934 55.934 106.499 SDR | Returns in order: input present, width, height, P (progressive) / I (interlaced), vertical refresh, colorspace, subsampling, bits per pixel, H total, V total, H freq (kHz), pixel clock (MHz), Dynamic Range. | Yes | 4.0 | Yes | No |
| INPUT.INFO | Get Input Information | 300 | ? | VC#.IN#and optional.... 0=BRIEF (DEFAULT) 1=ALL | String | INPUT.INFO(VC1.IN4)? INPUT.INFO(VC1.IN4):TRUE 1440 900 P 59.89 INPUT.INFO(VC1.IN4 BRIEF)? INPUT.INFO(VC1.IN4 BRIEF):TRUE 1440 900 P 59.89 INPUT.INFO(VC1.IN4 ALL)? INPUT.INFO(VC1.IN4 ALL):TRUE 1440 900 P 59.89 RGB 444 24 1904 934 55.934 106.499 | Returns in order: input present, width, height, P (progressive)/ I (interlaced), vertical refresh, colorspace, subsampling, bits per pixel, H total, V total, H freq (kHz), pixel clock (MHz). | Yes | 4.0 | Yes | No |
| INPUT.PRESENT | Source Connected | 302 | ? | VC#.IN# | 0=FALSE 1=TRUE | INPUT.PRESENT(VC3.IN4)? INPUT.PRESENT(VC3.IN4):FALSE | Returns if a source is active on the specified input. | Yes | 4.0 | Yes | No |
| MESSAGE.COUNT | System Message Count | 2324 | ? | | Integer | MESSAGE.COUNT? MESSAGE.COUNT:10 | Returns a count of the current system messages. | Yes | 5.1 | Yes | Yes |
| PANEL.POWER | Panel On/Off | 1538 | =? | PN# | 0=DISABLE=OFF=NO=FALSE 1=ENABLE=ON=YES=TRUE | PANEL.POWER? PANEL.POWER:0 | Gets / sets the backlight to on or off of the selected display | No | 7.0 | Yes | No |
| PANEL.RX.LENGTH | Data Cable Length | 1541 | ? | PN# | String | PANEL.RX.LENGTH(PN3)? PANEL.RX.LENGTH(PN3):"<20m" | Returns an estimate of the CAT cable from the VC to the specified panel. | No | 6.0 | Yes | No |
| PANEL.SIGNAL.QUALITY | Output Cable Signal Quality | 1536 | ? | PN# | String | PANEL.SIGNAL.QUALITY(PN2)? PANEL.SIGNAL.QUALITY(PN2):"-22dB, -22dB, -23dB, -22dB" | Returns panel signal quality as a string. | No | 5.1 | No | No |

| Command | Description | Numeric Command Code | Operators | Modifiers | Operands | Example | Notes | Standalone Component Command | Firmware Version Active | Functional in Fast Start Standby | Functional in Low Power Standby |
|---------------|------------------------------|----------------------|-----------|--------------|---|---|---|------------------------------|--------------------------|----------------------------------|---------------------------------|
| PANEL.VOLTAGE | Panel Voltage | 1514 | ? | 1-4294967295 | String | PANEL.VOLTAGE(8)? PANEL.VOLTAGE(8):48.12 | Returns the input voltage of a panel. | No | 5.1 | Yes | Yes |
| POWER.STATUS | External Device Power Status | 2701 | ? | PS# PSW# | 0=OFF 1=ON | POWER.STATUS(PSW2)? POWER.STATUS(PSW2):"OFF" | Gets the specified device power state. | Yes | 8.0 10.0 ¹ | Yes | No |
| PS.PRESENT | Power Module Present | 1422 | ? | 1-4 | 0=NOT_PRESENT 1=PRESENT 2=INVALID | PS.PRESENT(2)? PS.PRESENT(2):PRESENT | Returns if a power supply module is detected within the power supply. | Yes | 1.x | Yes | No |
| PS.STATUS | Power Module Status | 1423 | ? | 1-4 | String | PS.STATUS(3)? PS.STATUS(3):0x284A | <p>This command is used for critical health status of the RPSM; further diagnosis of an issue may need to be completed at the factory.</p> <p>Output will be in a hexadecimal format. Converting to binary and noting the position starting at the right (0 position) and noting the position of the non-zero character(s) up to the last (15) will indicate which faults were seen.</p> <p>Note: For the example shown, 284A, the hex value converts to 0010 1000 0100 1010. This indicates that 1, 3, 6, 11, and 13 were noted as fault conditions.</p> <p>0 = Unspecified fault 1 = Communication Memory Fault 2 = Module temperature may have exceeded the maximum 3 = VAC is below minimum 4 = IDC is above maximum 5 = VDC is above maximum 6 = Module DC is off 7 = Module is performing previously requested actions 8 = Unspecified fault 9 = Unspecified fault 10 = Fan failure 11 = Power status 12 = Unspecified Fault 13 = VAC fault warning 14 = IDC fault or warning 15 = VDC fault or warning 0xFFFFFFFF = Module not present, invalid or off</p> | Yes | 1.x | Yes | No |

| Command | Description | Numeric Command Code | Operators | Modifiers | Operands | Example | Notes | Standalone Component Command | Firmware Version Active | Functional in Fast Start Standby | Functional in Low Power Standby |
|----------------|----------------------|----------------------|-----------|--------------------|---|--|--|------------------------------|-------------------------|----------------------------------|---------------------------------|
| RUNTIME | Device Total On Time | 1429 | ? | VC# PS# PN# | String | RUNTIME(PS1)? RUNTIME(PS1):"1562:24" | Returns the total time on for the specified device in the format "HOURS:MINUTES". If no device is specified runtime is returned for the master component. | Yes | 5.1 | Yes | No |
| SYSTEM.STATE | System State | 2310 | ? | | 0=STANDBY 1=POWERING.ON 2=ON 3=POWERING.DOWN 4=BACKLIGHT.OFF 5=FAULT | SYSTEM.STATE? SYSTEM.STATE:STANDBY | Indicates the current state of the system. -STANDBY: The system is in its lowest power mode. Not all function are available -POWERING.ON: The system is transitioning from the STANDBY state to the ON state -ON: The system is on with the displays on -POWERING.DOWN: The system is transitioning from the ON state to the STANDBY state -BACKLIGHT.OFF: The system is on and the displays are off -FAULT: A system failure has occurred | No | 1.x | Yes | Yes |
| SYSTEM.VERSION | Firmware Version | 2302 | ? | | String | SYSTEM.VERSION? SYSTEM.VERSION:"4.0.567" | Returns the software version of the system based on the master component. | Yes | 1.x 4.0 ¹ | Yes | Yes |
| TEMPERATURE | Device Temperature | 1431 | ? | PN# VC# PS# | Float | TEMPERATURE(VC1)? TEMPERATURE(VC1):30.438000 | Returns the temperature of the specified device. If no modifier is provided, returns the temp of the master component. | Yes | 5.1 | Yes | No |
| UPTIME | Device On Time | 1430 | ? | PS# VC# | String | UPTIME(VC1)? UPTIME="4:16" | Returns the total time on since last reboot of the specified device in "HOURS:MINUTES". If no modifier is provided, returns the uptime of the master component. | No | 5.1 7.0 ¹ | Yes | No |
| VOLTAGE | Input AC Voltage | 1432 | ? | PS#.MODULE# PN# | Float | VOLTAGE(PS1.MODULE1)? VOLTAGE(PS1.MODULE1):118.203354 | Returns the voltage for the specified power supply module. | Yes | 5.1 6.0 ¹ | Yes | No |
| TIME.STRING | System Time | 1103 | ? | | String | TIME.STRING? TIME.STRING:"2018-12-14 22:59:30" | Returns system current date and time in a standard format. | No | 5.1 | Yes | No |

¹ Updated

Zone Setup and Control


| Command | Description | Numeric Command Code | Operators | Modifiers | Operands | Example | Notes | Standalone Component Command | Firmware Version Active | Functional in Fast Start Standby | Functional in Low Power Standby |
|----------------------|------------------------|----------------------|-----------|-----------|--|--|--|------------------------------|-------------------------|----------------------------------|---------------------------------|
| ZONE.ADD | Add Zone | 2605 | = | | Integer | ZONE.ADD(5)=0 0 1920 1080 ZONE.ADD(5): | Adds a zone number specified at in order: x pixel dimension from zero x position of wall, y pixel dimension from zero y position of wall, x pixel width, y pixel height. Only applicable to the active display/preset. | No | 4.0 | Yes | No |
| ZONE.ASPECT | Zone Aspect Ratio | 2610 | =? | | Integer 0=FILL 1=CROP 2=16X9 3=4X3 4=NATIVE 5=AUTO | ZONE.ASPECT(5)? ZONE.ASPECT(5):16X9 | Gets / sets the how to scale/zoom of source that does not fit the aspect ratio of a specified zone. Only applicable to the active display/preset. | No | 4.0 | Yes | No |
| ZONE.BACK | Send Zone to Back | 2613 | =? | | Integer | ZONE.BACK? ZONE.BACK:3 | Gets / sets the zone at bottom of the zone overlapping display area for the active display. | No | 4.0 | Yes | No |
| ZONE.CAPTURE.PERCENT | Zone Capture in % | 2612 | =? | | Integer 0.00 - 100.00 | ZONE.CAPTURE.PERCENT(5)=25 25 75 75 ZONE.CAPTURE.PERCENT(5):25 25 75 75 | Gets / sets for specified source in zone in order: x offset percentage from zero x position in zone, y offset percentage from zero y position in zone, source x percent capture area, source y percent capture area. Numbers are based on percentage of overall source dimensions. Only applicable to the active display/preset. | No | 4.0 | Yes | No |
| ZONE.CAPTURE.PIXEL | Zone Capture in Pixels | 2618 | =? | | Integer | ZONE.CAPTURE.PIXEL(5)=480 270 1440 810 ZONE.CAPTURE.PIXEL(5):480 270 1440 810 | Gets / sets for specified source in zone in order: x offset pixel from zero x position in zone, y offset pixel from zero y position in zone, source x pixel capture area, source y pixel capture area. Numbers are based on overall source pixels. Only applicable to the active display/preset. | No | 4.0 | Yes | No |
| ZONE.COUNT | Number of Zones | 2609 | ? | | Integer | ZONE.COUNT? ZONE.COUNT:8 | Returns the number of zones configured in the active display. | No | 4.0 | Yes | No |
| ZONE.DELETE | Delete Zone | 2600 | ! | | Integer | ZONE.DELETE(2) ZONE.DELETE(2)@ACK | Deletes specified zone from active display. | No | 4.0 | Yes | No |
| ZONE.DUPLICATE | Duplicate Zone | 2619 | = | # | Integer | ZONE.DUPLICATE(4)=8 ZONE.DUPLICATE(4):8 ZONE.DUPLICATE(7)=0 ZONE.DUPLICATE(7):8 | Creates duplicate zone with ID of operand based on the zone ID in the modifier. Operand of zero will create zone with the next numerically unassigned zone ID. | No | 9.0 | Yes | Yes |

| Command | Description | Numeric Command Code | Operators | Modifiers | Operands | Example | Notes | Standalone Component Command | Firmware Version Active | Functional in Fast Start Standby | Functional in Low Power Standby |
|-----------------------------|----------------------|----------------------|-----------|---|--|--|--|------------------------------|-------------------------|----------------------------------|---------------------------------|
| ZONE.EXPECTED.SOURCE.HEIGHT | Zone Source Height | 2617 | =? | Integer | Integer | ZONE.EXPECTED.SOURCE.HEIGHT(3)? ZONE.EXPECTED.SOURCE.HEIGHT(3):2160 | Gets / sets the input resolution height of the zone source. Only applicable to the active display/preset. | No | 4.0 | Yes | No |
| ZONE.EXPECTED.SOURCE.WIDTH | Zone Source Width | 2616 | =? | Integer | Integer | ZONE.EXPECTED.SOURCE.WIDTH(3)? ZONE.EXPECTED.SOURCE.WIDTH(3):3840 | Gets / sets the input resolution width of the zone source. Only applicable to the active display/preset. | No | 4.0 | Yes | No |
| ZONE.FRONT | Send Zone to Front | 2614 | =? | | Integer | ZONE.FRONT=2 ZONE.FRONT:2 | Gets / sets the zone at the top of the zone overlapping display area for the active display. | No | 4.0 | Yes | No |
| ZONE.ID | Set Zone ID | 2601 | = | 1-65535 | 1-65535 | ZONE.ID(5)=3 ZONE.ID(5):3 | Sets an existing zone ID to a new zone ID. If there are duplicate IDs, the first found will be changed. Only applicable to the active display/preset. | No | 4.0 | Yes | No |
| ZONE.INPUT | Assign Input to Zone | 2602 | =? | Integer | VC#.IN# | ZONE.INPUT(5)=VC2.IN3 ZONE.INPUT(5):VC2.IN3 | Gets / sets the source input for a specified zone. Only applicable to the active display/preset. | No | 4.0 | Yes | No |
| ZONE.JUSTIFY | Justify Zone | 2611 | =? | 1-65535 | 0=CENTER 1=LEFT 2=RIGHT 3=TOP 4=BOTTOM 5=TOP.LEFT 6=TOP.RIGHT 7=BOTTOM.LEFT 8=BOTTOM.RIGHT | ZONE.JUSTIFY(3)? ZONE.JUSTIFY:TOP.LEFT | Gets / sets the reference edge(s) of a zone source. Only applicable to the active display/preset. | No | 4.0 | Yes | No |
| ZONE.LIST | Zone ID List | 2603 | ? | Integer 1-ZONE.COUNTand/or.... Integer 1-ZONE.COUNT | String | ZONE.LIST? ZONE.LIST:1 2 3 5 6 7 8 9 10 ZONE.LIST(3)? ZONE.LIST:3 ZONE.LIST(4 8)? ZONE.LIST:4 5 6 7 8 | Returns a list of zone IDs associated with the active display. The optional modifiers enable listing when there are more than 64 zones. The first modifier gives the 1-based index into the list for the first returned value. If the second modifier is omitted, only one value is returned. When given, the second value specifies the end index of the returned values. | No | 4.0 | Yes | No |
| ZONE.MAXIMIZE | Maximize Zone | 2604 | ! | Integer | | ZONE.MAXIMIZE(3) ZONE.MAXIMIZE:@ACK | Sets a zone to display an image over the entire active area controlled by the system. Only applicable to the active display/preset. | No | 4.0 | Yes | No |

| Command | Description | Numeric Command Code | Operators | Modifiers | Operands | Example | Notes | Standalone Component Command | Firmware Version Active | Functional in Fast Start Standby | Functional in Low Power Standby |
|--------------|-------------------|----------------------|-----------|-----------|----------|---|---|------------------------------|-------------------------|----------------------------------|---------------------------------|
| ZONE.ORDER | Zone Stack Order | 2615 | =? | Integer | String | ZONE.ORDER(5)? ZONE.ORDER(5):-4 | Gets / sets the order position of the specified zone in the zone stack. Smaller numbers are toward the back. Only applicable to the active display/preset. | No | 4.0 | Yes | No |
| ZONE.RECT | Zone Display Area | 2606 | =? | Integer | String | ZONE.RECT(5)? ZONE.RECT(5):1920 1080 1920 1080 | Gets / sets for specified zone in configured wall in order: x offset pixel from zero x position in wall, y offset pixel from zero y position in wall, zone x area pixel size, zone y area pixel size. Only applicable to the active display/preset. | No | 4.0 | Yes | No |
| ZONE.RESTORE | Restore Zone | 2607 | ! | Integer | | ZONE.RESTORE(5) ZONE.RESTORE(5):@ACK | Undo of the last zone modification performed on the specified zone. Zone specified must have had the last action performed. Only applicable to the active display/preset. | No | 4.0 | Yes | No |
| ZONE.SOURCE | Zone Input | 2608 | =? | Integer | String | ZONE.SOURCE(1)? ZONE.SOURCE(1):"HDMI VC2.IN2" | Gets / sets the input routed to a zone. Only applicable to the active display/preset. | No | 4.0 | Yes | No |

Sending Serial Commands via USB

The USB-B connector accepts the same serial command set as RS232. As most PCs no longer have RS232 connections, using the USB-B connector becomes a convenient method for performing serial communication with the display.



Remote Power Supply Models



Video Controller Models

Installing the USB drivers

Before using USB for serial communication, the USB drivers must be installed. This section describes the steps necessary to install the USB drivers. You can skip this section if you have already installed the USB drivers on your computer. USB drivers may be obtained from the Planar Partner Portal website at <https://partners.planar.com/>

Automatically installing the USB drivers

In most cases, the USB driver installation can be performed using the automated driver installation program included on the USB flash drive in your accessory kit.


- If using a 64-bit version of Windows, use the CP210xVCPInstaller_x64.exe installation program.
- If using a 32-bit version of Windows, use the CP210xVCPInstaller_x86.exe installation program.

If you're unsure whether your machine is 32-bit or 64-bit, try both installation programs. If the selected program is for a different architecture, the installer will inform you to use the other installation program.


- 1 When the Planar USB Driver Installer page opens, click "Next".



- 2 The USB drivers will be automatically installed.




- 3 When the installation completes, click "Finish". The USB driver installation process is now complete.




Manually installing the USB drivers

If the automatic USB driver installation doesn't succeed, you can follow the steps below to manually install the USB drivers. The USB flash drive in your accessory kit contains the USB drivers for manual installation.


- 1 Plug in the USB cable to your computer and to the desired component.
- 2 Windows will detect the new hardware and attempt to install the drivers on its own. If you do not see the "Installing device driver software" message, then the driver installation previously failed. Skip to step 5.




- 3 If driver installation succeeds, you will see a message like the one shown below. If so, driver installation is complete.



- 4 If Windows' attempt at installing the drivers fails, you will need to manually install the drivers using the steps below.




5 Open the Start menu and select "Control Panel".




6 Select "Device Manager".


7 In the Device Manager, there will be a "Planar Display" item in the "Other Devices" section. Right-click on Planar Display and select "Update Driver Software".




- 8 Follow the steps defined in the Update Driver Software wizard as follows.
 - a On the initial screen, select “Browse my computer for driver software”.



- b Make sure the “Include subfolders” checkbox is checked. The USB drivers are included on the USB flash drive in the accessory kit; they can also be obtained from <http://www.planar.com/support>. Use the “Browse” button to locate the directory where the USB drivers are located. Click “Next”.



- c When the installation completes, click "Close". The USB driver installation process is now complete.




Note: Beginning with the release of Windows 10 v.1607, all drivers must be digitally signed by the Windows Hardware Developer Center Dashboard (WHDCD) portal. Planar is currently in process of having this driver signed by the WHDCD. If there are issues stating that no compatible driver is found when trying to recognize the device, a manual installation will be required. Follow these steps to enable the installation of the driver:

- 1 Click the **Start Menu** and select **Settings**.
- 2 Click **Update and Security**.
- 3 Click **Recovery**.
- 4 Click **Restart Now** under **Advanced Setup**.
- 5 Click **Troubleshoot**.
- 6 Click **Advanced Options**.
- 7 Click **Startup Settings**.
- 8 Click **Restart**.
- 9 When the Startup Settings screen appears, press either 7 or F7 to disable driver signature enforcement.


Once the computer reboots, it will be able to load unsigned drivers through the WHDCD until the next reboot of the PC.

Using the RPS USB Connection


Once the USB drivers are installed, the PC will recognize the USB-B connection as a regular serial port. The USB-B connection will appear in the COM port list of each serial terminal program. Any terminal program such as Tera Term can be used to test the connection.



The baud rate on the serial connection is set by default to 19200 on the hardware, so it may be necessary to update the baud rate in the software. From the Device Manager, right-click and select Properties.




Select the Port Settings tab from the window that opened and from the pull down menu under Bits per second select 19200.



Click OK and exit out of the Device Manager.

Sending Serial Commands Via TCP or UDP

The TCP and UDP port 57 accepts serial commands the same as the above methods. It is convenient for IP control applications and can be tested with a TCP terminal program such as Tera Term or a UDP terminal program such as Hercules; however, any Telnet program will work. Ensure the port is active through WallDirector Security Settings prior to attempting to use port 57.




Remote Power Supply Models




Video Controller Models

Note: Windows 10 has a command line based telnet capability that is not installed by default. To install, follow the instructions below:

1 Open **Control Panel**.




2 Open **Programs and Features**.




3 Select the **Turn Windows features on or off** option.


4 Select the **Telnet Client** check box.



- 5 Click **OK**. A box will appear that says “Windows feature” and “Searching for required files.” When complete, the Telnet client should be installed.





6. Open the program by searching from the **Start** menu.



Notice the following in the TCP example below using Tera Term:


- The default IP address is 192.168.0.12; however, if connected to a WAN, the IP address assigned by the network can be used.
- Port 57 is selected
- Service is set to "Other" to indicate that TCP is being used without Telnet or SSH



Notice the following in the UDP example below using Hercules:

- The default IP address is 192.168.0.12; however, if connected to a WAN, the IP address assigned by the network can be used.
- Port 57 is selected
- “69 6e 70 75 74 2e 69 6e 66 6f 28 76 63 31 2e 69 6e 31 20 61 6c 6c 29 3f 0d 0a” in the Send box is hex for “input.info(vc1.in1 all)?”

Note: Most UDP terminal programs won’t automatically send the [CR] at the end of the command, so the hex command (0d 0a) is used to do this manually.



Index

A

ALERT.CHECK, 11
 ALERT.CLEAR, 11
 ALERT.COUNT, 30
 AUTO.LAYOUT, 16
 AUTO.ON, 16

B

BACKLIGHT, 14
 BACKLIGHT.INTENSITY, 14
 BACKLIGHT.INTENSITY, 14
 BACKLIGHT.MAXIMUM, 16
 BACKLIGHT.MODE, 16
 BACKLIGHT.OFFSET, 15
 BREAKER.OPEN, 30

C

CABINET.INPUT, 16
 CABINET.INPUT.STATUS, 30
 CABINET.POLLING.ENABLE, 27
 CABINET.POLLING.INTERVAL, 27
 COLOR.TEMP, 15
 COMMAND.ENABLE, 29
 communicating via RS232 commands, 4
 CONNECTED, 30
 connecting
 RS232 cable, 5
 CONNECTION, 30
 CUSTOM.COLOR, 16

D

DEVICE.DELETE, 16
 DEVICE.GROUP, 16
 DEVICE.NAME, 16
 DEVICE.REBOOT, 11

F

FAN.STATUS, 30
 FIRMWARE.UPDATE, 17
 FIRMWARE.VERSION, 17
 FUSE.OPEN, 30

G

GENLOCK.AUTO, 17
 GENLOCK.DISABLE, 17
 GENLOCK.LOCKED, 31
 GENLOCK.REFERENCE, 17
 GRAY.BALANCE.GAMMA, 15

H

HDR.ENABLE, 17
 HELP, 11

I

ID, 17
 IDENTIFY, 17
 INFOFRAME, 31
 INPUT.BRIGHTNESS, 17
 INPUT.COLORSPACE, 18
 INPUT.CONTRAST, 18
 INPUT.GAIN, 18
 INPUT.INFO, 31
 INPUT.OFFSET, 18
 INPUT.PRESENT, 31
 INPUT.RESET, 18
 IPV4.ADDRESS, 18
 IPV4.ENABLE, 18
 IPV4.GATEWAY, 19
 IPV4.NETMASK, 19
 IR.CODE, 19
 IR.LOCK, 19

K

KEY, 12
KEY.LOCK, 19

L

LOCAL.DIMMING, 12
LOOP.ROUTE, 12
LOOP.ROUTE.AUTO, 13

M

MASTER.SWITCH, 13
MATRIX.LAYOUT.COLUMNS, 19
MATRIX.LAYOUT.PANEL, 19
MATRIX.LAYOUT.ROWS, 19
MENU.PANEL, 19
MESSAGE.CLEAR, 13
MESSAGE.COUNT, 31
MODEL.NAME, 19

N

NETWORK.CONFIG.MODIFIED, 20
NETWORK.DHCP, 20
NETWORK.DNS1, 20
NETWORK.DNS2, 20
NETWORK.MAC, 20
NETWORK.PING, 20
NTP.ENABLE, 20
NTP.SERVER, 20

O

OSD.ALLOW.POPUP, 20
OSD.MARGIN, 20
OSD.POSITION, 21
OSD.TIMEOUT, 21
OUTPUT.COLOR.DEPTH, 21
OUTPUT.MODE, 21
OUTPUT.VREFRESH, 21

P

PANEL.ACTIVE, 21

PANEL.ACTIVE.AUTO, 13
PANEL.BRIGHTNESS.OFFSET, 21
PANEL.COUNT, 21
PANEL.HEIGHT, 21
PANEL.ID, 21
PANEL.LIST, 22
PANEL.POSITION, 22
PANEL.POWER, 13, 31
PANEL.RECT, 22
PANEL.RX.LENGTH, 31
PANEL.SIGNAL.QUALITY, 31
PANEL.SYNC.ENABLE, 13
PANEL.VOLTAGE, 32
PANEL.XY, 22
PASSWORD.SET, 29
PATTERN, 22
POWER.COMMAND, 14
POWER.SAVING.DELAY, 23
POWER.SAVING.DELAY.MINUTES, 23
POWER.SAVING.MODE, 23
POWER.STATUS, 32
PRESET.ACTIVE, 28
PRESET.COUNT, 28
PRESET.DELETE, 28
PRESET.LIST, 28
PRESET.NAME, 28
PRESET.RECALL, 28
PRESET.SAVE, 28
PRESET.SLOT, 28
PRESET.STATUS, 28
PS.COUNT, 23
PS.LIST, 23
PS.PRESENT, 32
PS.STATUS, 32
PS.VERSION, 23

Q

QCONFIG, 14

R

RESET, 23
RESET.ALERTS, 27
RESET.BALANCE, 15
RESET.CANCEL, 23
RESET.LAYOUT, 23
RESET.PANEL, 13

RS232
 communication, 4
 connecting the cable, 5
 sending commands via UDP, 46
 RUNTIME, 33

S

SERIAL.DEVICE, 23
 SERIAL.NUMBER, 24
 SOURCE.ABSENT.COLOR, 24
 SOURCE.ABSENT.RGB, 24
 STANDBY.MODE, 24
 SYSTEM.PANEL.VERSION, 24
 SYSTEM.POWER, 14
 SYSTEM.POWER.TIE, 24
 SYSTEM.REBOOT, 14
 SYSTEM.STATE, 33
 SYSTEM.VERSION, 33

T

TEMPERATURE, 33
 TIME.STRING, 33
 TIMEZONE, 24
 TIMEZONE.STRING, 24

U

UPTIME, 33

V

VC.AUTO.ADDRESS.ENABLE, 24
 VC.AUTO.ENABLE.ADDRESS, 13
 VC.COUNT, 24
 VC.LIST, 25
 VC.START.ADDRESS, 25
 VOLTAGE, 33

W

WALL.BRIGHTNESS, 25
 WALL.HEIGHT, 25
 WALL.RGB.GAIN, 15
 WALL.WIDTH, 25

WHITE.BALANCE, 15

Z

ZONE.ADD, 34
 ZONE.ASPECT, 34
 ZONE.BACK, 34
 ZONE.CAPTURE.PERCENT, 34
 ZONE.CAPTURE.PIXEL, 34
 ZONE.COUNT, 34
 ZONE.DELETE, 34
 ZONE.DUPLICATE, 34
 ZONE.EXPECTED.SOURCE.HEIGHT, 35
 ZONE.EXPECTED.SOURCE.WIDTH, 35
 ZONE.FRONT, 35
 ZONE.ID, 35
 ZONE.INPUT, 35
 ZONE.JUSTIFY, 35
 ZONE.LIST, 35
 ZONE.MAXIMIZE, 35
 ZONE.ORDER, 36
 ZONE.RECT, 36
 ZONE.RESTORE, 36
 ZONE.SOURCE, 36